



Farberware FSTO100 Knob Replacement

One of the knobs is missing or broken. This guide will show step by step instructions on fixing or replacing the toaster knob.

Written By: Tony Wang




INTRODUCTION

Use this guide to replace a missing or broken knob with glue.

TOOLS:

- [Large Needle Nose Pliers](#) (1)
 - [Polyurethane Glue](#) (1)
-

Step 1 — Knob



- If a knob falls off, make sure metal tab is still in place.
- If not, insert metal tab into horizontal slot with pliers.

Step 2



- Apply glue to the inside of the knob.

Step 3



- Attach the knob to its original position and let dry.

To reassemble your device, follow these instructions in reverse order.

This document was last generated on 2017-06-28 01:09:46 AM.